


## INSTALLATION

- 1) Plug the CD Player into an electrical outlet. (Do not plug into a UPS battery backup)  
We recommend plugging the Player into a regular 110 electrical outlet, and not a battery back-up. (System has built in memory which will remember last programming sequence in case of a power outage.)



- 2) Connect the CD Player to the Wall-Mounted Phone System.

Connect one end of the audio cord to the back of the CD player as shown in the diagram above. Connect the other end of the audio cord into your wall-mounted phone system as demonstrated in the diagram below. If your phone system does not have an MOH Port, you'll need to splice the cable into your phone system.



- 3) Program your messages.  
Refer to programming instructions.

Note: CD Player will only hold up to 22 tracks. If more tracks are added the display will show FULL.

- 4) Adjusting the volume.

Then you can call your main phone line from another line at your location, and ask to be put on hold. If the sound quality is distorted, or the volume is too low even when turned all the way up, contact Customer Service at 1-800-373-8200. You may need an amplifier.