

## Info-Hold Programming Instructions For Protege

Note: You must use the remote control to activate the memory feature. If you do not, the player will not keep the programming in memory.

- 1.) Using your Track Legend, choose the messages you wish to program.
  - 2.) Turn the CD player "ON".
  - 3.) Ⓜ Press "OPEN/CLOSE" and insert the compact disc (side with writing up) into tray, press "OPEN/CLOSE".
  - 4.) Use the numbered buttons to program tracks. (For 1 through 10 press 1 through 10.
  - 5.) Tracks higher than 10, use > 10 then the numbered buttons
- EXAMPLE To program track 30. First press button >10, then button 3, then button 10.)

After all selections have been made, verify that "Program" and "Repeat" are shown on the display. Then press "PLAY"

**TO ERASE:** Press "STOP" then "CLEAR" UNTIL  
All the tracks in the display are cleared