

## Cordless Terminal User's Guide

## Cordless Terminal User's Guide

IP3NA-12TXH(BT) TEL ( )  
IP3NA-BCH ADAPTER ( )

Dealer name



Please cooperate with recycling of a lithium ion battery.

Li-ion

NEC Infrontia Corporation

A50-013717-002 Issue 2.0  
2008.7

- Before using your product, read this User's Guide thoroughly to ensure correct handling.
- After reading the User's Guide, keep it in a place that is accessible for read reference.

# **LIABILITY DISCLAIMER**

NEC Infrontia Corporation reserves the right to change the specifications, functions, or features, at any time, without notice.

NEC Infrontia Corporation has prepared this document for use by its employees and customers. The information contained herein is the property of NEC Infrontia Corporation and shall not be reproduced without prior written approval from NEC Infrontia Corporation. All brand names and product names on this document are trademarks or registered trademarks of their respective companies.

Copyright 2008

**NEC Infrontia Corporation**

# Warning

- ◆ Do not use the unit if you notice smoke, a strange smell or other unusual happenings. It may cause fire if you continuously use it. Turn off the power switch of the phone system immediately. For the recharger, disconnect the power plug immediately. Confirm that smoke has ceased, and then contact your dealer.  
Never attempt to repair the unit by yourself.
- ◆ If you had an accident such as dropping the phone and broke the unit, turn off the power of the phone system immediately. For the recharger, disconnect the power plug immediately. Contact your dealer.  
If you keep using the unit, it may cause fire or electrical shock.
- ◆ If water spilled into the unit, turn off the power of the phone system immediately. For the recharger, disconnect the power plug immediately. Contact your dealer. If you keep using the unit, it may cause fire or electrical shock.
- ◆ Do not insert flammable or metal objects into the units. If a foreign object was accidentally placed into the unit, turn off the power of the phone system and unplug the power adapter. Contact your dealer. If you keep using the unit, it may cause fire or electrical shock. Pay special attention to children to prevent from similar accidents.
- ◆ Do not attempt to disassemble or modify the units. It may cause fire, electrical shock, or system malfunction.  
Modification by a user is prohibited by law.
- ◆ Do not open the unit intentionally. It may cause electrical shock or system malfunction.  
Ask for test adjustment, and repair of the unit from your dealer.
- ◆ Do not twist, put a heavy object, and push the phone system. Such actions may cause damage, fire, or injuries.
- ◆ Do not place a container with water such as a vase, a plant pot, a cup, cosmetics, chemicals, nor a small metal object. Splashing water over the units and foreign metal object inserted into the units may cause fire or electrical shock.
- ◆ Do not use the unit in a high humid area such as a bathroom or near a humidifier. They may cause fire, electrical shock, or system malfunction.
- ◆ Use the specified power adapter, which is attached to the unit. Other adapters may cause fire or system malfunction.

---

---

---

---

---

---

## *Warning*

- ◆ Do not damage, or modify the power adapter cord. Do not kink, pull, twist, or bundle it. Do not put a heavy object onto it. Do not heat it. It may cause fire, electrical shock, or system malfunction. Contact your dealer if you have a damaged adapter cord.
- ◆ Do not touch the power plug with a wet hand. It may cause electrical shock or system malfunction.
- ◆ Do not touch the unit or replace a battery with a wet hand. It may cause electrical shock or system malfunction.
- ◆ When you hear thunder outside during use of the phone system, immediately stop using it and move to a safe place.
- ◆ Do not use multiple plugs on a single outlet. It may cause fire or electrical shock.
- ◆ Follow the instruction below when you use a battery pack to avoid overheating, explosion, and fire;
  - Do not put the battery pack into a microwave oven or a pressure chamber.
  - Do not use other batteries with this battery pack.
- ◆ If the internal battery liquid touches your skin or clothes, immediately rinse it with clean water to prevent chemical damage.
- ◆ Do not use the phone or recharge the battery in a place where fire or explosion may occur.
  - This phone system does not have explosion protection. Do not use it where a flammable gas such as propane and gasoline are stored. Turn off the power of the phone immediately. Do not recharge the battery in such a place.
- ◆ Do not use near microwave ovens, medical equipment and industrial equipment.

# User Safety Protocol

**Important:** Read this information before using your IP3NA-12TXH(BT) TEL( ) and IP3NA-BCH ADAPTER( ).

Read the following instructions to use this product safely and to prevent you and other people from possible injury, and to protect properties. Improper handling may cause overheating, explosion, and fire.

***Danger***

- ◆ Recharge the battery with the matching battery charger only (see battery label description).
- ◆ Use the battery only for this IP3NA-12TXH(BT) TEL( ) and IP3NA-BCH ADAPTER( ) system. Do not use it with other electrical devices.
- ◆ Heed the following warnings to prevent the battery pack from overheating, explosion, and fire.
  - Do not throw the battery pack into a fire.
  - Do not solder the battery pack directly.
  - Do not short the positive (+) and negative (-) terminal of the battery pack with metal.
  - Do not poke the battery or smash it with a hammer.
- ◆ Do not disassemble or modify the battery pack. It has a safety circuit and a damaged circuit may cause overheating, explosion, and a fire.
- ◆ The internal liquid of the battery pack has strong acid. If the battery liquid gets into your eye, rinse your eye well with water and consult with a doctor.
- ◆ Do not use, leave, or recharge the battery pack near fire or under the direct sunlight. High temperature may damage the internal safety circuit and may cause malfunction of the recharge, overheating, explosion, or fire.

## FCC Portion

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

### **Caution:**

Any changes or modifications not expressly approved by the party responsible for product compliance could void the user's authority to operate the equipment.

### **RF Exposure Guidelines**

#### **LO(BTC)B / LO(BTC)U**

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

#### **LO(BTH)B / LO(BTH)U**

To comply with FCC RF exposure compliance requirements, this device must not be collocated or operating in conjunction with any other antenna or transmitter.

LO(BTH)B or LO(BTH)U was tested with BELTCLIP(BTH)( ). Use only this beltclip to ensure FCC Compliance. The use of third-party beltclips may not comply with FCC RF exposure compliance requirements, and should be avoided.



# Introduction

Thank you very much for purchasing our cordless terminal.

## < Devices covered >

- IP3NA-12TXH(BT) TEL()
- IP3NA-BCH ADAPTER()

A cordless terminal is a multifunctional terminal with a portable handset that lets you originate calls and answer terminating calls from within a certain talking range.

A standard multifunctional terminal may have its handset replaced with a IP3NA-BCH ADAPTER( ) to transform into a cordless terminal.

Each cordless terminal consists of the following devices:

- Bluetooth<sup>®</sup> Terminal: A multifunctional terminal unit to which a Bluetooth<sup>®</sup> Cradle (BTC) is connected.
- Bluetooth<sup>®</sup> Handset (BTH)

Instructions in this User's Guide focus on Bluetooth® handset operations. For instructions about handling the Bluetooth® terminal, refer to the manual that comes with your system.

## How This Guide Is Organized

## Before Using the Product

Provides tips and hints on using the product safely and properly, and topics of prerequisite importance to using the cordless terminal.



## Bluetooth® Handset Operations

Explains operating tips and the handset functions of the cordless terminal.



## Troubleshooting

Explains how to deal with troubles that may occur while you use the cordless terminal.



# Table of Contents

Warning .....	i
User Safety Protocol .....	iii
FCC portion .....	iv
Industry Canada Portion .....	v
Introduction .....	vi
How This Guide Is Organized .....	vi
Table of Contents .....	vii

---

## Before Using the Product ..... 1-1

---

About Cordless Terminals .....	1-2
Bluetooth® Terminal and Bluetooth® Handset .....	1-2
Key Functions .....	1-2
Talking Range .....	1-4
Charging .....	1-5
Replacing the Battery .....	1-6
In the Event of a Power Failure .....	1-7
Wall-Mounting Kit for the Bluetooth® Terminal .....	1-7
Primary Specifications .....	1-8
Safety Precautions .....	1-10
Operating Instructions and Maintenance .....	1-14
Locating the Bluetooth® Terminal .....	1-14
Antenna .....	1-15
Radio Transmission .....	1-15
Radio Interference .....	1-16
Maintenance .....	1-16
Charging Terminals .....	1-17
Operation Following Power Feeding to the Bluetooth® Terminal .....	1-17

---

Component Names and Functions .....	1-18
Bluetooth® Terminal .....	1-18
Bluetooth® Handset .....	1-19
Bluetooth® Handset LCD Screen .....	1-20
Displayed Information .....	1-20
Explanations of Icons .....	1-22
Adjusting the Bluetooth® Handset .....	1-24
Configuring the Cordless Terminal .....	1-25
Configuring the Bluetooth® Terminal .....	1-25
Configuring the Bluetooth® Handset .....	1-27
Transforming the Standard Handset into a IP3NA-BCH ADAPTER( ) .....	1-29
Connecting a Headset .....	1-36
Pairing with a Bluetooth® Headset .....	1-36
Connecting a Corded Headset .....	1-38
Using the Belt clip .....	1-39

---

Bluetooth® Handset Operations .....	2-1
-------------------------------------	-----

---

Caution .....	2-2
Bluetooth® Handset Functions .....	2-3
Key Lock .....	2-3

---

Troubleshooting .....	3-1
-----------------------	-----

---

Troubleshooting Tips .....	3-2
----------------------------	-----

---

---

---

---

---

---

---

---

## Before Using the Product

About Cordless Terminals .....	1-2
Safety Precautions .....	1-10
Operating Instructions and Maintenance .....	1-14
Component Names and Functions .....	1-18
Bluetooth® Handset LCD Screen .....	1-20
Adjusting the Bluetooth® Handset .....	1-24
Configuring the Cordless Terminal .....	1-25
Transforming the Standard Handset into a IP3NA-BCH ADAPTER( ) .....	1-29
Connecting a Headset .....	1-38



## About Cordless Terminals

A cordless terminal is a multifunctional terminal that interconnects its Bluetooth® terminal and Bluetooth® handset with each other using Bluetooth® wireless technology to maintain calls or perform other operations between them.

### Bluetooth® Terminal and Bluetooth® Handset

- The Bluetooth® terminal can be handled the same way as a telephone. Its Bluetooth® handset can be handled likewise, except for some of its features. If a particular feature of a terminal does not work, use the Bluetooth® terminal to enable it.
- If the Bluetooth® handset is out of service, return it to the Bluetooth® terminal to keep it charged at all times.
- Where multiple cordless terminals are set up, be careful to retain the pairing between the Bluetooth® cradle and Bluetooth® handset.

### Key Functions

The table below summarizes the key functions of a cordless terminal. For information about the functions of the multifunctional telephone itself, refer to the manual that comes with your system.



The ways you originate calls from the Bluetooth® headset and answer terminating calls may vary depending on the type of device you use.

Function		Description
Bluetooth® Terminal	Bluetooth® headset call	<p>You can register a Bluetooth® headset with the Bluetooth® cradle and use it.</p> <ul style="list-style-type: none"><li>• Originating calls to an extension or central office line Press the headset call (call control) button twice briefly and then dial on the terminal.</li><li>• Answering terminating calls Press the headset call (call control) button while a call terminates with a ring tone.</li></ul>


Function		Description
Bluetooth® Terminal	Bluetooth® headset call	<ul style="list-style-type: none"> <li>* For the latest recommended product information, please consult with your system provider for a list of compatible headsets.</li> <li>* Try to use a recommended headset to ensure that it connects to the cradle successfully and with the correctly matched sound volume.</li> <li>* The Bluetooth® headset cannot be used while you are talking with the Bluetooth® headset on. You cannot switch to the Bluetooth® headset while you are using the Bluetooth® headset, either.</li> <li>* The headset call (control key) button allows you to only originate calls from the headset and answer terminating calls.</li> </ul> <p>Any other headset-specific functions are not supported.</p>
Bluetooth® Handset	LCD display	<p>A 20-position-by-2-line LCD screen displays the date, time, phone number and more.</p> <p>Icons, such as those designating the status of radio and the remaining battery voltage, appear on the first line.</p> <ul style="list-style-type: none"> <li>* LCD displays may not be produced depending on your system.</li> </ul>
	Line keys	<p>Allows the functions pre-programmed on line keys 1 to 8 in the Bluetooth® terminal to be used.</p> <ul style="list-style-type: none"> <li>* For the functions that are available with the Bluetooth® handset, refer to the manual that comes with your system.</li> </ul>
	Incoming call/charging lamp	Lights or blinks when calls terminate or the Bluetooth® handset is charged.
	Key touch tone	Provides an audible verification of each click on a dial key.
	Tone type	<p>When calls terminate, a ring tone sounds from the speaker in the cordless terminal. The ring tone sounds in different ways depending on the status of the Bluetooth® handset:</p> <ul style="list-style-type: none"> <li>• Charging (handset returned to the cradle) Sounds from the speaker in the cradle only</li> <li>• Standby (handset removed from the cradle) Sounds from both the cradle and handset speakers</li> </ul>
	Volume/density control	Allows you to use the cursor keys, to adjust the receiver and ring tone volumes, and the LCD contrast.

Function		Description
Bluetooth® Handset	Terminal function	Allows you to originate calls to an extension or central office line, answer terminating calls and more, all in Bluetooth® handset operations.
	Hold/Transfer	Places calls on hold and forward them to another terminal.
	Histories of originating and terminating calls	Displays up to 10 originating and up to 10 terminating calls (up to 20 calls in total), including the latest calls. * This function may be unavailable the number of calls that can be displayed may vary depending on your system.

## Talking Range

The Bluetooth® terminal and Bluetooth® handset can be separated from each other about 50m at the farthest as a line-of-sight distance. This talking range, however, may shorten depending on the office environment in which the Bluetooth® terminal and Bluetooth® handset are used; for example, they are used near a metal or concrete wall.

If the handset gets too far away from the Bluetooth® terminal, the antenna mark will disappear accompanied by an alarm tone.







- You may have difficulty originating a call by dialing from the Bluetooth® handset. In this case, wait for a while and retry the dialing operation.
- Consult your dealer if you wish to use a cordless terminal together with an office cordless telephone in the same environment.
- Check the talking range of your Bluetooth® headset with its manual.

## Charging


Before you use the Bluetooth® handset for the first time or using the handset after it has been left out of use for a long time, charge it for at least 5 hours. (Full charging takes about 16 hours to complete.) A fully charged handset will allow you to talk for about 8 hours continuously and stand by for about 30 hours if low-power mode is enabled or for about 15 hours if low-power mode is disabled.

The remaining battery voltage icon appearing in the LCD screen, coupled by the incoming call/charging lamp and an alarm tone, alerts you to the remaining battery voltage of the Bluetooth® handset. The table below describes how these indications appear depending on the remaining battery voltage of the handset.

Remaining battery voltage	State indications			Remarks
	Icon	Incoming call/charging lamp	Alarm Tone	
High		–	–	
Medium		–	–	
Low		–	–	
Charging required	 Blinking	Blinking red	✓	When an alarm tone sounds during a call, hang up as soon as possible and charge the battery.
Charging in progress	–	Fully charged : Lit green Charging : Lit red	–	
Charging error	–	Blinking orange	–	

## Replacing the Battery

The battery loaded in the Bluetooth® handset has a useful life of about 2 years, though it is a parameter of on how the handset has been used. If the battery voltage diminishes quickly after the battery has been charged for a long time, replace with a new battery (Li-ion BATTERY - option). For more details, ask your dealer.



This product is powered by a lithium-ion battery.

Lithium-ion battery: 3.7V 1100mAh

The lithium-ion battery is a recyclable resource.

When recycling batteries that have been replaced or that have been taken out of a used product, take notice of this precaution to avoid smoking and firing:

- Take proper precautions when discarding the battery. It may be considered hazardous material in some areas.
- There is a danger of explosion if the battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by NEC. Return old batteries to the battery supplier, a licensed battery dealer or a designated collection facility.
- Bring batteries to our repair counter with the contacts being taped to prevent shorts or enclosed individually in plastic bags.

<Our repair counter> For more details, visit the NEC Infrontia Environment Website.

**URL** <http://www.necinfrontia.co.jp/english/company/environment/index.htm>

Do not disassemble, tamper or damage the battery pack.

Please send your queries to:

- Dealer from whom your product or lithium-ion battery was purchased
- Our repair counter



## **In the Event of a Power Failure**

Your cordless terminal will behave in the following manners:

- The charging function is shut down to keep the system battery from draining depending on your system.
- The cordless terminal may be disabled depending on the system battery voltage.
- The cordless terminal is disabled if the system battery is exhausted.
- Calls in progress will be cleared if the system battery is exhausted in the meantime.
- If an optional AC adapter is used, the cordless terminal cannot be charged while the power failure persists.

## **Wall-Mounting Kit for the Bluetooth® Terminal**

You can use this product on a wall by attaching the optional kit to wall-mount the Bluetooth® terminal. Contact your dealer about getting the kit.

## Primary Specifications

Item	Dimension	Remarks
Bluetooth® version	Bluetooth® version 2.0	
Radio interface	Bluetooth® Class1 (1mW to 100mW)	
Installed profiles	Bluetooth® Handset (BTH) <ul style="list-style-type: none"> <li>• GAP : Generic Access Profile</li> <li>• SPP : Serial Port Profile</li> </ul>	
	Bluetooth® Cradle (BTC) <ul style="list-style-type: none"> <li>• GAP : Generic Access Profile</li> <li>• SPP : Serial Port Profile</li> <li>• HSP : Headset Profile</li> <li>• HFP : Hands Free Profile</li> </ul>	* For the latest information on recommended Bluetooth® headset, please consult with your system provider for a list of compatible headsets. * Try to use a recommended headset to ensure that it connects to the cradle successfully and with the correctly matched sound volume.
Operating range	About 50m (line-of-sight distance)	Dependent on the environment.
Power consumption	Bluetooth® Handset (BTH): About 0.5W	
	Bluetooth® Cradle (BTC) : About 1.5W	Including the power used to charge the handset.
Power feeding method	Power feeding from the multifunctional terminal	
Option	AC adapter	Used only if the distance from the main unit exceeds 400m.
Dimensions (L × W × H)	Bluetooth® Handset (BTH): 53mm × 183mm × 47mm	
	Bluetooth® Cradle (BTC): 69mm × 223mm × 81mm	Excluding the antenna.
Mass	Bluetooth® Handset (BTH): About 0.17kg	Including the battery.
	Bluetooth® Cradle (BTC): About 0.33kg	Excluding the line cord.

Item	Dimension	Remarks
Operating environment	Temperature : 0 to 40℃ Relative humidity : 10 to 90%	No dew condensing.
Restrictions	Keep the cordless terminal at least 1m apart from other cordless terminals and at least 3m apart from other radio equipment	



Cordless terminals operate on a digital radio principle and are made less susceptible to interception by third parties. Radio waves used by the cordless terminals, however, threaten the chances of intentional interception. To dismiss concerns over possible interception by third parties, use a fixed-line telephone.

- \* The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by NEC Infrontia Corporation is under license. Other trademarks and trade names are those of their respective owners



## Safety Precautions

This User's Guide uses various pictorial markings to alert you to the precautions you need to observe to safeguard you and others and prevent property damage.

The meanings of such pictorial markings and graphic symbols are defined below. Understand these definitions fully before proceeding to read the main text.



### **DANGER**

- Indicates a situation in which an impending risk of human death or severe physical injury is anticipated.



### **WARNING**

- Indicates a situation in which a possibility of human death or severe physical injury is anticipated.



### **CAUTION**

- Indicates a situation in which a possibility of physical injury or property damage is anticipated.

### **NOTICE**

- Indicates a situation that could result in a failure of intended performance of this system or in a functional shutdown.

### ***Examples of Pictorial Markings***



The △ symbol alerts you to a caution (including a danger or warning), which is depicted within the marking (in this example, explosion possible).



The ⊘ symbol alerts you to a prohibited action, which is depicted within the marking (in this example, no tampering or taking apart).



The ● symbol alerts you to a requirement or suggestion, which is depicted within the marking.

## **DANGER**



- Observe these precautions when using a lithium-ion battery pack:
  - Only charge the pack from the main unit.
  - The lithium-ion battery pack has a specified connector orientation. When inserting the pack into the unit, observe the correct connector orientation.
  - Do not charge it with the lithium-ion battery pack unit.
  - Use the specified type of lithium-ion battery pack. Do not use the specified type of lithium-ion battery pack for any other device.
  - Do not dispose of the lithium-ion battery pack in fires or by heating it in any form.
  - Do not make direct soldering connections to the lithium-ion battery pack.
  - Do not disassemble or tamper the lithium-ion battery pack.
  - Do not carry or store the lithium-ion battery pack together with metallic products, which could cause the pack leaking, overheating or explosion.



- If the internal fluid in the lithium-ion battery pack should come into contact with the eyes, it could cause damaged to the eyes. Flush the eyes with plenty of fresh water immediately, without rubbing them, and obtain medical attention promptly.

## **WARNING**



- Do not remove the casing of the lithium-ion battery pack or scratch it. This could cause the pack to leak, heat or explode.



- If the internal fluid in the lithium-ion battery pack should contact the skin or clothes, it could cause physical harm to the skin. Flush with plenty of fresh water immediately.



- Do not soak the lithium-ion battery pack in water or seawater or moisten it. This could cause the pack to heat or rust.



- Discontinue using the lithium-ion battery pack whenever any signs of abnormality, such as leakage, discoloration or deformation, are noticed.



- Do not use the lithium-ion battery pack in bathrooms or shower rooms. This could cause the pack to short-circuit, resulting in fires or electrical shock hazards.



- Do not use the lithium-ion battery pack where it may be splashed or come into contact with water. This could cause the pack to short-circuit, resulting in fires or electrical shock hazards.



## WARNING



- Do not disassemble or tamper the unit. This could result in fires or electrical shock hazards.



- Do not allow water inside the lithium-ion battery pack or allow it to come into contact with water. This could cause the pack to short-circuit, resulting in fires or electrical shock hazards.



- Do not operate or make connections to this unit with wet hands. This could result in electrical shock hazards.



- Do not put flower vases, plant pots, cups, cosmetics, containers filled with chemicals, water or small metallic objects on top of the unit. This could result in fires or electrical shock hazards if they spill or penetrate the interiors of the unit.



- Do not insert metallic objects or put metallic objects the interiors of the unit through openings. This could result in fires, electrical shock hazards or failures.



- If it is necessary to use an AC adapter, use one of the types. Otherwise, fires, electrical shock hazards or failures could result.



## CAUTION



- Do not violently shake to the lithium-ion battery pack or throw it.



- Keep the lithium-ion battery pack out of reach of infants and children.



- Do not leave the lithium-ion battery pack in a place exposed to direct sunlight or in a hot place. A heightened internal temperature could result in fires.



- Do not place the unit in a place where it could be splashed with hot oils or exposed to steam (such as near a cooking table) or in a dusty place. This could result in fires or electrical shock hazards.



- Mount the unit securely. An insecure or unstable location could cause the unit to fall and cause physical injury.



- Do not block ventilation holes in the unit. This could cause heat to build up inside the unit, resulting in fires.



## CAUTION



- Do not place the unit in a location which is liable to have frequent vibration or impact. This could cause the unit to fall, resulting in physical injury.



- Be careful not to let the antenna of a cordless terminal stick into your eyes by mistake.



- Do not short-circuit the charging terminals.



- Do not charge the handset seated in the cradle while the charging terminals are wet.




- If foreign matter or water should penetrate the inside of the terminal, disconnect the line cord and AC adapter immediately and contact your dealer.

## NOTICE

- To use the unit safely and properly, avoid installing it in these places:
  - Places where there is excessive dust or vibration.
  - Places that are filled with vaporized chemicals or the unit may be exposed to chemicals.
  - Places close to radios or TV receivers or sources of intense magnetic fields.
  - Places in which there are sources of high-frequency interference nearby, such as high-frequency sewing machines or electric welders.


# Operating Instructions and Maintenance

In using cordless terminals, take notice of these instructions in particular.



## Locating the Bluetooth® Terminal


- If multiple cordless terminals are installed, keep their Bluetooth® terminals at least 1m apart from one another.
- Do not install the Bluetooth® terminal near a metal, concrete wall or any other structure that could affect radio transmission, as this may cause a communication failure.
- Keep the Bluetooth® terminal at least 3m apart from any of the devices listed below. Be also careful not to get within 3m of these devices when using the Bluetooth® handset. Before locating the cradle, ask your dealer for a safety validation.
  - Microwave ovens
  - Wireless LAN access points (AP)
  - Medical apparatus
  - RFID (apparatus operating in the 2.4 GHz band)
  - Manufacturing equipment, such as plasma strippers (LSI manufacturing)
  - Speedway electronic toll gates
  - Bluetooth® devices






## Antenna

Put the antenna of the Bluetooth® terminal in an upright position while in use.  
The antenna will bend or break if it is given undue force.



## Radio Transmission

Cordless terminals may not work or may be affected by interference if they are used near a broadcasting station or near sources of intense radio transmission, such as ham radio and CB radio. Because radio equipment might be disabled in the presence of radio interference, ask your dealer for preliminary environmental measurement. In installing new radio equipment after the system has been installed as well, request a preliminary verification of freedom from radio interference. If interference is detected after the system is installed, they may not be corrected.



### **Tips on Radio Transmission**

The working frequency band of this device is shared by industrial, scientific and medical equipment, such as microwave ovens, premises radio stations that are typically used in manufacturing lines at plants for mobile identification (radio stations that require licensing) and specified low-power radio stations (license-free radio stations).

- Before using this device, check that premises radio stations for mobile identification and specified low-power radio stations are not used nearby.
- If any case of radio interference arises from a premises radio station used for mobile identification, discontinue radio transmission from this device immediately and contact your dealer for advice on how to take action for avoiding the interference.
- Further, if any case of radio interference arises from a specified low-power radio station used for mobile identification or any troubles develop, contact your dealer.
- The ring tone sounding time and call starting time of Bluetooth® handset are slightly delayed compared to the Bluetooth® terminal in some cases due to radio transmission characteristics.

## **Radio Interference**

Cordless terminals are designed to heighten radio output automatically as the separation between the Bluetooth® terminal and Bluetooth® handset widens, thereby maintaining a satisfactory state of communication.


Heightened radio output could cause radio interference to neighboring equipment. In this occurs, keep the Bluetooth® terminal farther apart from the neighboring equipment.

## **Maintenance**

If the Bluetooth® terminal and Bluetooth® handset get dirty, wipe their surfaces with a soft, dry cloth. If they are heavily soiled, wipe them with a diluted solution of a kitchen detergent and then wipe them off with a dry cloth.


Never use organic solvents, such as alcohol, benzine and thinner, for cleaning; these chemicals could damage the surfaces of the terminal.

Also, avoid using a chemical duster.



## Charging Terminals

Keep the charging terminals of the Bluetooth® cradle and Bluetooth® handset always clean. Wipe dust off the charging terminals with a dry cotton swab at least once a month or rub them with a cotton swab moistened with alcohol.



In cleaning the charging terminals, be sure not to:

- Touch the terminals with hands directly
- Short-circuit the terminals.


## Operation Following Power Feeding to the Bluetooth® Terminal

Because cordless terminals use radio transmission between their Bluetooth® terminal and Bluetooth® handset, they may take about 15 seconds after the line cord is installed into the Bluetooth® cradle before calls can be made between the Bluetooth® cradle and Bluetooth® handset.

If the Bluetooth® handset goes off-hook or the Conference or Talk key is pressed in the meantime, the error tone “pi-pi-pi-pi” may sound without a wireless (line) connection being established.



## Bluetooth® Handset



## Bluetooth® Handset LCD Screen


The Bluetooth® handset LCD screen displays certain information as described below according to the status of the terminal. For information about the Bluetooth® terminal LCD screen, refer to the manual that comes with your system.

### Displayed Information

The new terminal mode screen shows an example for when your system is Aspire X. Note that display content may be different or lost if another system is used.

### ▼ Standby Sample Display

The information shown below is displayed when the terminal is not used.

	First line	• First line : Icon
	Second line	• Second line : Date and time
	Third line	• Third line : Extension number and line
	Fourth line	• Fourth line : Active line key number

For explanations of the icons, see “Explanations of Icons” ([P.1-22](#)).


## ▼ If an Originating or Terminating Call History Is Displayed

If an originating or terminating call history is displayed, the history number of a call and date and time are displayed, along with the remote party's name or telephone number. (P.2-3)

<Originating call history>



<Terminating call history>



The display may differ depending on your system.


## ▼ If the Setup Screen Is Displayed

If the Setup Screen is displayed, the title of a setup item and its setting are displayed. For more details, see “Configuring the Bluetooth® Handset” (P.1-27).

<Volume/Density control>














<Item selection>




## Explanations of Icons

The table below summarizes the explanations of the icons that appear on the first and fourth lines in the LCD screen.

Icon	Explanation		
	Antenna marks	High ↑ ↓ Low	<p>Indicates the strength of radio transmission between the Bluetooth® terminal and Bluetooth® handset.</p> <p>* If you move to a place with lower strength of radio transmission from a place where your terminal indicates low strength of radio transmission (▼), a no service tone sounds. When you move to a service area, the no service tone stops and you can continue calling. The no service tone can be disabled by settings on the handset. For more details, see “No Service Tone” in “Configuring the Bluetooth® Handset” (P.1-27).</p> <p>* If no service (no display) occurs while no service tone is sounding during a call, the call is dropped.</p> <p>* No service (no display) indicates that the terminal is out of reach of radio transmission. You can neither make nor receive calls.</p>
			
			
			
		No service	
	Ring tone OFF		<p>Displayed when the terminal is configured to suppress the ring tone. For more details, see “Ring Volume” in “Configuring the Bluetooth® Handset” (P.1-27).</p>
	Unheard voice mail notification		Displayed when there are voice mails in the mailbox yet to be heard.
	Key lock		Displayed when a key lock has been set. For more details, see “Key Lock” (P.2-3)
	Unanswered call history yet to be confirmed		Displayed when there is a history of unanswered terminating messages yet to be confirmed.
	Remaining battery voltage		Indicates the remaining voltage of the battery. For more details, see “Charging” (P.1-5).
	Available cursor display		Indicates the directions of the cursor keys available.



Icon	Explanation	
	Line key status display	Indicates the numbers of active line keys.



Some icons may not be displayed depending on your system.


## Adjusting the Bluetooth® Handset

You can adjust the volumes of various tones and the display density of the Bluetooth® handset using the up and down cursor keys.

### ▼ Adjusting the Receiver Volume

You can adjust the volume of the voice that is heard from the handset.

Press the up and down cursor keys (up: high, down: low) while you are talking on the handset.



### ▼ Adjusting the Ring tone Volume

You can adjust the volume of the ring tone of the Bluetooth® handset.

Press the up and down cursor keys (up: high, down: low) while the ring tone sounds.

If you want to adjust the ring tone volume while the ring tone does not sound, do as instructed in "Ring Volume" in "Configuring the Bluetooth® Handset" (P.1-27).


The ring tone OFF icon appears in the LCD screen if the ring tone volume is turned off.



### ▼ Adjusting the LCD Density

You can adjust the contrast of the LCD screen.

Press the up and down cursor keys (up: dark, down: light) while the standby panel is on display.



# Configuring the Cordless Terminal


## Configuring the Bluetooth® Terminal

Start configuring Bluetooth® device from the Bluetooth® terminal setup menu.



The following operation is an example. Display content may vary depending on connected terminal and your system.

- Press the Menu button. → Accept [3. Settings] → Accept [5. Peripherals] → Accept [1. Bluetooth].



The table below lists the setting of each setup item.

Menu display		Setting ([ ] default)	Explanation
Pairing Mode	Pairing	-	Up to 8 Bluetooth® devices are located around the Bluetooth® terminal, among which select a headset you want to pair with the multifunctional terminal. For more details, see “Pairing with a Bluetooth® Headset” (P.1-36).
	PIN Code	4 to 16 digits [0000]	Before pairing, you need to set the PIN Code of the Bluetooth® terminal and the Bluetooth® headset. When pairing with a Bluetooth® headset that has a PIN Code other than 0000, enter a string of 4 to 16 digits to suit that device. For more details, see “Pairing with a Bluetooth® Headset” (P.1-36). *The PIN Code is a password that is exchanged between Bluetooth® devices preparatory to launching a session of communication between them.

Menu display	Setting ([ ] default)	Explanation
Visibility	[1. Disable] 2. Enable	<ul style="list-style-type: none"> <li>• Always set to “Disable”.</li> </ul>
BT Information	-	<p>You can view the following kinds of information about the Bluetooth® terminal:</p> <ul style="list-style-type: none"> <li>• Firmware Version</li> <li>• Hardware Version</li> <li>• BT Module</li> <li>• BT Profile (Bluetooth® standard)</li> <li>• SPP (SPP profile version)</li> <li>• HSP (HSP profile version)</li> <li>• HFP (HFP profile version)</li> <li>• Device Address</li> <li>• Device Name</li> </ul>

## ▼ Key Operations at Menu Setup (Bluetooth® Terminal)

Key		Description
Cursor keys	Up	<ul style="list-style-type: none"> <li>• Moves up the highlighted item.</li> </ul>
	Down	<ul style="list-style-type: none"> <li>• Moves down the highlighted item.</li> </ul>
	Left	<ul style="list-style-type: none"> <li>• Returns to the last page.</li> </ul>
	Right	<ul style="list-style-type: none"> <li>• Accepts the highlighted item and displays the next page.</li> </ul>
	Enter	<ul style="list-style-type: none"> <li>• Accepts the highlighted item and displays the next page.</li> <li>• Saves the change and returns to the last page.</li> </ul>
Dial keys		<ul style="list-style-type: none"> <li>• Accept the item of a number pressed and display the next page.</li> <li>• Accept the setting of the pressed number.</li> <li>• Enter numerals.</li> </ul>
Exit key		<ul style="list-style-type: none"> <li>• Cancels an operation and returns to the standby panel.</li> </ul>

## Configuring the Bluetooth® Handset

On the Bluetooth® handset while in standby mode, press the [HOLD] > [TRF] keys and then press dial keys (1) to (6) to see a Setup Screen associated with the dial key pressed.

The table below lists the setting of each item.



The handset will return to the standby panel automatically if 4 minutes pass with the no action being launched from the menu.

Dial key	Item	Setting ([ ] default)	Explanation
(1)	Base Call	-	Allows you to call the paired Bluetooth® terminal and identify it when it is unknown.
(2)	Key Touch Tone	<ul style="list-style-type: none"> <li>• Disable</li> <li>• [Enable]</li> </ul>	Set to sound a confirmation tone each time a key is pressed or not.
(3)	Ring Volume	Off (0), 1 to [8] to 13	Adjusts the ring tone volume. The ring tone OFF icon appears on the LCD screen if the ring tone volume is turned off.
(4)	No Service Tone	<ul style="list-style-type: none"> <li>• Disable</li> <li>• [Enable]</li> </ul>	Set to sound a no service tone when no service occurs.
(5)	Low Power Mode	<ul style="list-style-type: none"> <li>• Disable</li> <li>• [Enable]</li> </ul>	Set to enter to low-power mode automatically when no calls or key operations have been launched for a long time.
(6)	Font Size	<ul style="list-style-type: none"> <li>• [Double Height]</li> <li>• Normal</li> </ul>	Set to display the characters on the two lines in the middle of the LCD screen in double or normal height. * Characters will display in normal height while a setup item is on display.



You cannot originate calls or answer terminating calls while the Bluetooth® menu setup is in progress. Exit the menu before originating calls or answering terminating calls. However, you can originate calls and answer terminating calls with the Bluetooth® terminal.

## ▼ Key Operations at Setup (Bluetooth® Handset)

---

Key		Description
Cursor keys	Up	<ul style="list-style-type: none"><li>• Moves up the highlighted item.</li><li>• Raises the volume or density.</li></ul>
	Down	<ul style="list-style-type: none"><li>• Moves down the highlighted item.</li><li>• Lowers the volume or density.</li></ul>
	Left	<ul style="list-style-type: none"><li>• Cancels an operation and returns to the standby panel.</li></ul>
	Enter	<ul style="list-style-type: none"><li>• Accepts the highlighted item and returns to the standby panel.</li></ul>
END key		<ul style="list-style-type: none"><li>• Cancels an operation and returns to the standby panel.</li></ul>

## Transforming the Standard Handset into a IP3NA-BCH ADAPTER( )

The IP3NA-BCH ADAPTER( ) is an optional device that transforms the standard multifunctional terminal into a cordless terminal. This section explains how to transform the standard handset into a IP3NA-BCH ADAPTER( ).

### ▼ Supported Telephone Type

The IP3NA-BCH ADAPTER( ) can be connected to the following types of terminal:

Telephone type	Description	Remarks
Digital multifunctional terminal	<ul style="list-style-type: none"> <li>• IP3NA-12/24 TXH TEL(WH/BK)</li> <li>• IP3NA-8LTXH TEL(WH/BK)</li> </ul>	Not connectable to the IP3NA-2TH TEL(BK) and IP3NA-6TXH TEL(BK)




If the IP3NA-BCH ADAPTER( ) is connected to a terminal, the following optional devices cannot be connected at the same time:

- IP3WW-APR ADAPTER
- IP3WW-ADA ADAPTER
- IP3NA-BHA ADAPTER
- IP3NA-PSA ADAPTER( )


### ▼ Replacement Procedure

- 1 Turn over the terminal.**
- 2 Remove the standard handset.**  
Release the curl cord from the groove and out its modular plug from the HANDSET connector on the back of the terminal.
- 3 Lower the tilt legs to the first level.**

- 4** Release lugs a and b on the stopper from grooves A and B in the tilt legs and widen the tilt legs.




- 5** Slide the tilt legs to front out of position while pushing claws c and d.






- 6** Tilt the standard handset cradle stopper towards the cradle until it is released with a click.
- 7** Slide the standard handset cradle farther away to remove.
- 8** Remove the cradle connecting cable from the terminal unit connector.



- 9** Insert the cradle connecting cable of the Bluetooth<sup>®</sup> cradle into the terminal unit connector.
- 10** Insert the lug on the terminal unit into the hole in the Bluetooth<sup>®</sup> cradle.


Have the cradle connecting cable passed in the groove to keep it from being pinched.

**11** Slide the Bluetooth® cradle.




**12** Push the Bluetooth® cradle until the stopper clicks into position.

**13** Fit the cradle connecting cable in the groove to clamp.




- 14** Detach the rubber-like connector cover of the bottom unit connector on the multifunctional terminal.




- 15** Insert the claws at the lower part of the bottom unit connected to the Bluetooth<sup>®</sup> cradle, and then attach the bottom unit to the terminal connector while pushing the upper claw.

Secure the bottom unit to the terminal unit.



**16** Uncover the bottom unit mounted in the Bluetooth® cradle while holding its knob.

**17** Stow the extra length of the bottom unit connecting cable at the bottom unit connector and close the cover.




**18** Cut the coupled device of the tilt legs for handset option with nippers.

The coupled device is supplied with the handset cradle.

**19** Insert the stopper coupled device into the right and left stoppers of the tilt legs for handset option to couple them.


**20** Insert the coupled device for tilt legs firmly into the right and left tilt legs of the tilt legs for handset option.



**21** The tilt legs in original position.

**22** Place the Bluetooth® handset in the Bluetooth® cradle.

**23** Erect the antenna of the Bluetooth® cradle.



The transformation of the standard handset into a IP3NA-BCH ADAPTER( ) is complete.

## Connecting a Headset

The following kinds of headsets can be used with a cordless terminal:

- Bluetooth® Terminal side : Bluetooth® headset, corded headset
- Bluetooth® Handset side : Corded headset

The method of connecting each headset is as follows.

### Pairing with a Bluetooth® Headset


A Bluetooth® headset can be connected to the Bluetooth® terminal. To perform pairing, follow these steps:

**1 Open the Bluetooth® device setup screen in the Bluetooth® terminal LCD screen.**


For instructions on how to open the setup screen, see “Configuring the Bluetooth® Terminal” (P.1-25).

If the Bluetooth® headset has a PIN code of ‘0000’, go to Step 3; else, go to Step 2.

**2 On the Bluetooth® screen, select [1. Pairing Mode] > [2. PIN Code] in this order. Enter a PIN Code (4 to 16 digits) to suit the Bluetooth® device and press the OK key.**



- 3** On the Bluetooth® screen, select [1. Pairing Mode] > [1. Pairing] > [1. -- Bluetooth Headset --] in this order and select a Bluetooth® headset to pair with from a list of Bluetooth® devices located.



It takes approximately one minute for locating.

- 4** Select [1. <Paired Headset>] > [2. Connect] > [2. Enable] in the pairing screen in this order and press the OK key.



**Pairing between the Bluetooth® headset and the Bluetooth® terminal is completed.**



After pairing, be sure to configure the cradle connection with the Bluetooth® headset in Step 4 to enable it. If connection setting is not done, the Bluetooth® headset cannot be used.

Before pairing your Bluetooth® headset in use with the Bluetooth® terminal, cancel the connection (or standby mode) with the Bluetooth® device in use. Then connect the Bluetooth® headset to the Bluetooth® terminal and use it.

Do not connect the Bluetooth® headset that is paired with the Bluetooth® terminal to other Bluetooth® devices. Doing so may disable operations for originating and terminating calls.



#### To unpair a paired Bluetooth® headset

Select [1. Delete] in the Bluetooth® Headset screen in Step 4 above to switch to a Delete screen. Press the OK key to unpair the paired Bluetooth® headset.


## ▼ Visibility Setting


Always set to “Disable”.

## Connecting a Corded Headset

You can connect a corded headset to the Bluetooth® handset.

For the latest information on recommended the corded headset, please consult with your system provider for a list of compatible headsets.

Insert the headset plug firmly into the headset jack (bearing the  mark in the cover) on the right side of the Bluetooth® handset.






## Using the Belt clip

### 1 Belt clip installation

The belt clip allows you to attach the Bluetooth® handset to a belt.



Insert the belt clip into the three holes on each side of the Bluetooth® handset, and press it down until it clicks.



Make sure that all the claws are firmly inserted.

### 2 A state of use

Using the belt clip allows you to wait and receive incoming calls.



Wearing the corded headset allows you to talk without holding the Bluetooth® handset.



The talking range is about 50 m.





## Bluetooth® Handset Operations

Caution .....	2-2
Bluetooth® Handset Functions .....	2-3



### Caution

Take notice of these instructions when operating a cordless terminal:

- Cordless terminals take a certain length of time before they enable you to talk. Cordless terminals also take some time before switching a call originated by on-hook dialing to the Bluetooth® handset after the other party picks up.
- The Talk lamp on the Bluetooth® handset may light green while it stands-by off-hook after a dialing operation performed from the Bluetooth® terminal. Press the Bluetooth® handset key to switch the call to the Bluetooth® handset.
- When making a phone call from the Bluetooth® handset after pressing the Talk or Conference key, make sure you hear a dial tone before pressing dial keys. Dial keys pressed before a dial tone is heard will be ignored.
- For operating instructions on using line keys, refer to the manual that comes with your system.


# Bluetooth® Handset Functions

## Key Lock

You can lock the Bluetooth® handset keys to disable them from being tampered with.

### ▼ How To Enable the Key Lock

- 1** Press the Transfer key for 2 seconds.
- 2** A key lock icon appears in the LCD screen.



If a call terminates while the key lock is enabled

Press the Talk key, blinking line key or Conference key to answer the terminating call. While the call is in progress, the key lock is temporarily overridden to make all keys functional. Hang up to return to the key lock enabled state.

### ▼ How to disable

- 1** Press the Transfer key for 2 seconds.
- 2** The key lock icon disappears from the LCD screen.







# Troubleshooting

Troubleshooting Tips ..... 3-2



## Troubleshooting Tips

If you suspect a failure, try the actions recommended in the table below first. If the problem persists or the symptom you are experiencing is not listed here, call your dealer and request service.

Symptom	Point to check	Action
Shut down completely	<ul style="list-style-type: none"> <li>• Is the Bluetooth® cradle cord out of position?</li> <li>• Is the battery correctly loaded?</li> <li>• Is the battery charged?</li> <li>• Is the handset too far away from the Bluetooth® terminal? (Does the antenna mark in the Bluetooth® handset LCD screen show “Low Strength” or is it off?)</li> </ul>	<ul style="list-style-type: none"> <li>• Inset the Bluetooth® terminal cord firmly into position.</li> <li>• Reload the battery correctly.</li> <li>• The battery may have been exhausted. If the handset still fails when the battery is fully charged, replace the battery.</li> <li>• Get closer to the Bluetooth® terminal to operate.</li> </ul>
Ring tone does not sound	<ul style="list-style-type: none"> <li>• Is the ring tone volume turned OFF? (Does the ring tone OFF appear in the Bluetooth® handset LCD screen?)</li> <li>• Is the battery correctly loaded?</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the ring tone volume.</li> <li>• Reload the battery correctly.</li> </ul>
Voice is disrupted while talking	<ul style="list-style-type: none"> <li>• Does the antenna mark in the handset LCD screen show “Low Strength” or is it off?</li> <li>• Is there an obstacle, such as a concrete wall, between the Bluetooth® terminal and Bluetooth® handset?</li> </ul>	<ul style="list-style-type: none"> <li>• Get closer to the Bluetooth® terminal to operate.</li> <li>• Move to a location clear of intervening obstacles.</li> </ul>



Symptom	Point to check	Action
Noise heard while talking	<ul style="list-style-type: none"> <li>• Is there any home appliance or OA equipment nearby?</li> </ul>	<ul style="list-style-type: none"> <li>• Electrical equipment can be a source of radio interference. Keep apart from electrical equipment.</li> </ul>
Calls do not last long than 10 minutes even though the battery has been charged for 8 hours or longer	<ul style="list-style-type: none"> <li>• Is the Bluetooth® handset correctly seated in the Bluetooth® cradle?</li> <li>• Are the charging terminals dirty?</li> <li>• Has the handset been used within two years?</li> </ul>	<ul style="list-style-type: none"> <li>• Keep the Bluetooth® handset properly seated in the Bluetooth® cradle.</li> <li>• Wipe off dirt from the charging terminals of the Bluetooth® cradle and Bluetooth® handset with a dry cloth.</li> <li>• The battery may have been exhausted if two years have passed since the handset was first used. Replace the battery.</li> </ul>
Remote party's voice hard to hear	<ul style="list-style-type: none"> <li>• Is the Bluetooth® handset receiver volume set low?</li> </ul>	<ul style="list-style-type: none"> <li>• Press the up cursor key while talking to adjust the receiver volume.</li> </ul>
It sometimes when the Talk or Conference key are pressed, their respective lamps blink but do not stay continuously lit and the call is not established, with an error tone "pi-pi-pi-pi" sounding from the Bluetooth® handset.	<ul style="list-style-type: none"> <li>• Radio interference may be at fault.</li> <li>• Is there any source of radio interference nearby?</li> <li>• Is the cradle at least 3m apart from the equipment mentioned in "Locating the Bluetooth® Terminal" (P.1-14) ?</li> <li>• Is there any device near the Bluetooth® handset that is mentioned in "Locating the Bluetooth® Terminal" (P.1-14) ?</li> </ul>	<ul style="list-style-type: none"> <li>• Press the Talk or Conference key one again.</li> <li>• Keep the Bluetooth® terminal and Bluetooth® handset at least 3m apart from sources of possible radio interference.</li> </ul>